

BS2_GetUserListFromDirWithKey 1
..... 1
..... 1
..... 1
..... 1

BS2_GetUserListFromDirWithKey

[+2.8.2] USB Data 가 .

```
#include "BS_API.h"

int BS2_GetUserListFromDirWithKey(void* context, const char* szDir, char**
uidsObj, uint32_t* numUId, IsAcceptableUserID ptrIsAcceptableUserID, const
BS2EncryptKey* key);
```

- [In] *context* : Context
- [Out] *szDir* : Data
- [Out] *uidsObj* :
- [Out] *numUId* :
- [In] *ptrIsAcceptableUserID* : user ID callback
- [In] *key* : [BS2_SetDataEncryptKey](#) .



BS_SDK_SUCCESS , 가

- [BS2_GetUserDatabaseInfoFromDirWithKey](#)
- [BS2_GetUserInfosFromDirWithKey](#)
- [BS2_GetUserDatasFromDirWithKey](#)
- [BS2_GetUserInfosExFromDirWithKey](#)
- [BS2_GetUserDatasExFromDirWithKey](#)
- [BS2_GetLogFromDirWithKey](#)
- [BS2_GetLogBlobFromDirWithKey](#)

[BS2_GetFilteredLogFromDirWithKey](#)

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getuserlistfromdirwithkey

Last update: **2022/04/12 15:25**