

BS2_GetVoipConfig	1
.....	1
.....	1
.....	1

Configuration API > BS2_GetVoipConfig

BS2_GetVoipConfig

Voip 가

```
#include "BS_API.h"

int BS2_GetVoipConfig(void* context, uint32_t deviceId, BS2VoipConfig*
config);
```

BS2VoipConfig

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : Voip

BS_SDK_SUCCESS , 가

From:

<http://kb.supremainc.com/bs2sdk/> - BioStar 2 Device SDK

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getvoipconfig

Last update: 2017/06/28 11:27