

BS2_SetRS485Config 1
..... 1
..... 1
..... 1

BS2_SetRS485Config

RS485

```
#include "BS_API.h"

int BS2_SetRS485Config(void* context, uint32_t deviceId, BS2Rs485Config* config);
```

[BS2Rs485Config](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : RS485

BS_SDK_SUCCESS , 가

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_setrs485config

Last update: **2016/07/12 09:30**