

**BS2\_SetSlaveExDevice** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

## BS2\_SetSlaveExDevice

가 CoreStation

가 /

.

```
#include "BS_API.h"

int BS2_SetSlaveExDevice(void* context, uint32_t deviceId, uint32_t
channelPort, BS2Rs485SlaveDeviceEX* slaveDevices, uint32_t
slaveDeviceCount);
```

[BS2Rs485SlaveDevice](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *channelPort* : channel port
- [In] *slaveDevices* : slave device
- [In] *slaveDeviceCount* : slave device

BS\_SDK\_SUCCESS , 가

.

### [BS2\\_GetSlaveExDevice](#)

From: <http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link: [http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_setslaveexdevice](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_setslaveexdevice)

Last update: **2017/08/29 08:46**

