

Table of Contents

BS2_SetKeepAliveTimeout

Declaration

Parameter

Return Value

.....

.....

.....

.....

1

1

1

1

[Device API](#) > [BS2_SetKeepAliveTimeout](#)

BS2_SetKeepAliveTimeout

Sets the keep-alive timeout.

Declaration

```
#include "BS_API.h"

int BS2_SetKeepAliveTimeout(void* context, long ms);
```

Parameter

- [In] *context* : Context
- [In] *ms* : Keep-alive timeout (microsecond)

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setkeepalivetimeout&rev=1531790500

Last update: **2018/07/17 10:21**