

## Table of Contents

|   |   |
|---|---|
| <b><i>BS2_SetKeepAliveTimeout</i></b> ..... | 1 |
| Declaration .....                           | 1 |
| Parameter .....                             | 1 |
| Return Value .....                          | 1 |

Device API > BS2\_SetKeepAliveTimeout

## BS2\_SetKeepAliveTimeout

Sets the keep-alive timeout.

### Declaration

```
#include "BS_API.h"  
  
int BS2_SetKeepAliveTimeout(void* context, long ms);
```

### Parameter

- [In] *context* : Context
- [In] *ms* : Keep-alive timeout (microsecond) Default value is 30,000,000.

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

From:

<http://kb.supremainc.com/bs2sdk/> - BioStar 2 Device SDK

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_setkeepalivetimeout&rev=1531790604](http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setkeepalivetimeout&rev=1531790604)

Last update: **2018/07/17 10:23**