

Table of Contents

USB Exported Control API	1
---------------------------------	---

USB Exported Control API

This API allows to control/manage USB Exported.

- [BS2_AllocateUsbContext](#): [Deprecated] Allocates context which manages & controls USB device.
- [BS2_ReleaseUsbContext](#): [Deprecated] Releases context which manages & controls USB device.
- [BS2_GetUserDatabaseInfoFromDir](#): Gets total user information(Number of user/card/fingerprint/face) from USB exported data.
- [BS2.GetUserListFromDir](#): Gets the enrolled user ID list from USB exported data.
- [BS2_GetUserInfosFromDir](#): Gets the user information of the given user ID from USB exported data.
- [BS2_GetUserDatasFromDir](#): Gets the user information of the given user ID & usermask from USB exported data.
- [BS2_GetUserInfosExFromDir](#): Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- [BS2_GetUserDatasExFromDir](#): Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- [BS2 GetUserSmallInfosFromDir](#): [+ 2.6.3] Gets the user information of the given user ID from USB exported data.
- [BS2 GetUserSmallDatasFromDir](#): [+ 2.6.3] Gets the user information of the given user ID & usermask from USB exported data.
- [BS2 GetUserSmallInfosExFromDir](#): [+ 2.6.3] Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- [BS2 GetUserSmallDatasExFromDir](#): [+ 2.6.3] Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- [BS2_GetLogFromDir](#): Gets certain amount of logs from USB exported data.
- [BS2_GetLogBlobFromDir](#): Gets certain amount of logs based on the event mask from USB exported data.
- [BS2_GetFilteredLogFromDir](#): Gets filtered logs from USB exported data.
- [BS2_GetLogSmallBlobFromDir](#): [+ 2.6.4] Gets certain amount of logs based on the event mask from USB exported data in an efficient way.
- [BS2_GetLogSmallBlobExFromDir](#): [+ 2.7.1] Gets certain amount of logs including temperature information based on the event mask from USB exported data in an efficient way.
- [BS2_GetUserInfosFaceExFromDir](#): [+2.7.1] Gets the user information of the given user ID from USB exported data.
- [BS2_GetUserDatasFaceExFromDir](#): [+2.7.1] Gets the user information of the given user ID & usermask from USB exported data.

[+2.8.2] USB Exported, ! °ü, ®Çİ±â ÀŞÇÑ APIÀÔ'Í'Ù.

»çzëÀÚ °ü, ÁÖçä 1°" Á¤º, 'Á ÀåÄi ³»zı¼ »çÀüzı Á¤ÀÇµÈ Á° °¤À, ·í ¾ïÈ£È µÇ¾í ÀúÀåµÈ'Í'Ù.
„ÀÍ [BS2_SetDataEncryptKey](#) ÇÔ¼ö, ! ÀìzëÇi Çò ÀåÄiÀÇ »çzëÀÚ Á¤º, ¾ïÈ£È Á°, ! °-°æÇÑ ÀûÀÌ ÀÖ'Ù, é,
USB°ü, Á API, ! ÀìzëÇi±â ÀŞÇØ ÇØ'ç Á° °¤À» Àü'þÇØ ÁÖ¾í¾ß ÇÖ'Í'Ù.

- [BS2_GetUserDatabaseInfoFromDirWithKey](#): [+2.8.2] Gets total user information(Number of user/card/fingerprint/face) from USB exported data.
- [BS2_GetUserListFromDirWithKey](#): [+2.8.2] Gets the enrolled user ID list from USB exported data.
- [BS2_GetUserInfosFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID from

USB exported data.

- [BS2_GetUserDatasFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID & usermask from USB exported data.
- [BS2.GetUserInfosExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- [BS2.GetUserDatasExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- [BS2.GetUserSmallInfosFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID from USB exported data.
- [BS2.GetUserSmallDatasFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID & usermask from USB exported data.
- [BS2.GetUserSmallInfosExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID from USB exported data. (Including Job, phrase)
- [BS2.GetUserSmallDatasExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID & usermask from USB exported data. (Including Job, phrase)
- [BS2.GetLogFromDirWithKey](#): [+2.8.2] Gets certain amount of logs from USB exported data.
- [BS2.GetLogBlobFromDirWithKey](#): [+2.8.2] Gets certain amount of logs based on the event mask from USB exported data.
- [BS2.GetFilteredLogFromDirWithKey](#): [+2.8.2] Gets filtered logs from USB exported data.
- [BS2.GetLogSmallBlobFromDirWithKey](#): [+2.8.2] Gets certain amount of logs based on the event mask from USB exported data in an efficient way.
- [BS2.GetLogSmallBlobExFromDirWithKey](#): [+2.8.2] Gets certain amount of logs including temperature information based on the event mask from USB exported data in an efficient way.
- [BS2.GetUserInfosFaceExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID from USB exported data.
- [BS2.GetUserDatasFaceExFromDirWithKey](#): [+2.8.2] Gets the user information of the given user ID & usermask from USB exported data.

From:

<https://kb.supremainc.com/kbtest/> - **BioStar 2 Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:use_exported_control_api&rev=1650844622

Last update: **2022/04/25 08:57**