

<b>BS2_GetInputConfigEx</b>	.....	1
.....	.....	1
.....	.....	1
.....	.....	1
.....	.....	1

Configuration API > BS2\_GetInputConfigEx

## BS2\_GetInputConfigEx

[+ 2.8.1] IM-120 Input

가

```
#include "BS_API.h"

int BS2_GetInputConfigEx(void* context, uint32_t deviceId, BS2InputConfigEx*
config);
```

BS2InputConfigEx

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : Input

BS\_SDK\_SUCCESS

, 가

From:

<http://kb.supremainc.com/bs2sdk/> - BioStar 2 Device SDK

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_getinputconfigex](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getinputconfigex)

Last update: 2021/08/05 10:30