

BS2_GetLogBlobFromDir	1
.....	1
.....	1
.....	1
.....	1
.....	1

USB Exported Control API > BS2_GetLogBlobFromDir

BS2_GetLogBlobFromDir

[+ 2.5.0] USB Data EventMask

가

```
#include "BS_API.h"

int BS2_GetLogBlobFromDir(void* context, const char* szDir, uint16_t
eventMask, BS2_EVENT_ID eventId, uint32_t amount, BS2EventBlob** logsObj,
uint32_t* numLog);
```

BS2EventBlob

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *eventMask* : event mask
- [In] *eventId* : ID , 0 가 .
- [In] *amount* : , 0 eventId 가 .
- [Out] *logsObj* :
- [Out] *numLog* :

logsObj

BS2_ReleaseObject

BS_SDK_SUCCESS , 가

BS2_AllocateUsbContext

BS2_ReleaseUsbContext
BS2.GetUserDatabaseInfoFromDir
BS2.GetUserListFromDir
BS2.GetUserInfosFromDir
BS2.GetUserDatasFromDir
BS2.GetUserInfosExFromDir
BS2.GetUserDatasExFromDir
BS2.GetLogFromDir
BS2.GetFilteredLogFromDir

From:

<http://kb.supremainc.com/bs2sdk./> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getlogblobfromdir

Last update: **2018/10/30 16:22**