

BS2_GetRS485ConfigEx 1
..... 1
..... 1
..... 1

BS2_GetRS485ConfigEx

CoreStation RS485 가 .

```
#include "BS_API.h"

int BS2_GetRS485ConfigEx(void* context, uint32_t deviceId, BS2Rs485ConfigEX* config);
```

BS2Rs485ConfigEX

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : RS485

BS_SDK_SUCCESS , 가

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getrs485configex

Last update: **2018/03/12 08:46**