Table of Contents

How to register Command card	1
Command card types	
Registering command cards on BioStar	
Deleting Command cards	:

BioStar 1, Command Card

How to register Command card


Command card types

There are three types of Command cards as follows:

- **Enroll Card**: After tapping an Enroll Card on the device's card reader, you can add a card to the device by tapping the card that you want to add on the reader.
- **Delete Card**: After tapping a Delete Card on the device's card reader, you can delete a card from the device by tapping the card that you want to delete on the reader.
- **Delete All Card**: Tapping a Delete All Card on the device's card reader will delete all the cards registered on the device.


Registering command cards on BioStar

1. Go to the **Command Card** tab on the **Device** page.




2. Click **Read Card** and tap a card on the card reader of the device to read the card number.

Delete Apply to Others Apply




3. Click Add and then Apply.

.



Deleting Command cards

1. Go to the **Command Card** tab on the **Device** page.



2. Select an Enroll Card on the Command Card list (the left pane) and click **Delete** and then **Apply**.

