

Table of Contents

How to Activate Biostar 2 License	1
Before you activate	1
How to Activate Biostar 2 License	1
Video Demo	4

[System Configuration](#), [BioStar 2](#), [License](#)

How to Activate Biostar 2 License


Before you activate

1. What is supported with BioStar 2's licenses?

Refer to the [FAQ article](#) for details.


2. What are global zone and local zone?

- Global Zone : TCP/IP based zone configuration (BioStar 2 server is a master of the zone)
- Local Zone : RS485 based zone configuration (Master device is a master of the zone)
- The zone master makes logical decisions and controls functionality




How to Activate Biostar 2 License

1. Go to the global setting and click **SERVER**.




2. Check if the server is connected to the Internet. If connected, you can activate via online.

3. Enter the customer site name and activation key and click **Activate**. You can receive activation key from Suprema or your local distributor.




4. If the server is not connected to the Internet, click **Request offline Key** and download offline key request file.



5. Send the offline key request file to Suprema and receive the offline license key in return.

6. Activate the license and check the information about compatible FW versions to use the updated new features.



7. Activated license status can be checked from the Server setting and **About**.

License

Access Control

- Applied License: Advanced
- Issued to: Peter
- Expiry date: None

Time Attendance

- Activate License Online:
- Activate License Offline:


Video

- Issued to: Peter
- Expiry date: None

Visitor

- Issued to: Peter
- Expiry date: None

About ✕



BioStar 2

- **BioStar Version** V2.8.14.72
- **AC Version** V2.8.14.49
- **TA Version** V2.8.13.36
- **Video Version** V2.8.12.1
- **Access Control** Applied License: Advanced
Issued to: Peter
Expiry date: None
- **Video** Issued to: Peter
Expiry date: None
- **Visitor** Issued to: Peter
Expiry date: None

© 2021 Suprema Inc. All rights reserved.

Video Demo

[license.mp4](#)

From:

<http://kb.supremainc.com/knowledge/> -

Permanent link:

http://kb.supremainc.com/knowledge/doku.php?id=en:how_to_activate_license&rev=1682404158

Last update: **2023/04/25 15:29**