

# Table of Contents

- How to Activate Biostar 2 License ..... 1
- Before Activating Biostar 2 License ..... 1
- How to Activate License for Biostar 2 Version 2.8.16 and Lower ..... 1
- Video Demo for Activating License for Biostar 2 Version 2.8.16 and Lower ..... 4

[System Configuration](#), [BioStar 2](#), [License](#)

## How to Activate Biostar 2 License


### Before Activating Biostar 2 License

1. What is supported with BioStar 2's licenses?

Refer to the [FAQ article](#) for details.


2. What are global zone and local zone?

- Global Zone : TCP/IP based zone configuration (BioStar 2 server is a master of the zone)
- Local Zone : RS485 based zone configuration (Master device is a master of the zone)
- The zone master makes logical decisions and controls functionality




### How to Activate License for Biostar 2 Version 2.8.16 and Lower

1. Go to the global setting and click **SERVER**.




2. Check if the server is connected to the Internet. If connected, you can activate via online.

3. Enter the customer site name and activation key and click **Activate**. You can receive activation key from Suprema or your local distributor.




4. If the server is not connected to the Internet, click **Request offline Key** and download offline key request file.



5. Send the offline key request file to Suprema and receive the offline license key in return.

6. Activate the license and check the information about compatible FW versions to use the updated new features.



7. Activated license status can be checked from the Server setting and **About**.

License

**Access Control**

- Applied License: Advanced
- Issued to: Peter
- Expiry date: None

**Time Attendance**

- Activate License Online:
- Activate License Offline:


**Video**

- Issued to: Peter
- Expiry date: None

**Visitor**

- Issued to: Peter
- Expiry date: None

About ✕



# BioStar 2

- **BioStar Version** V2.8.14.72
- **AC Version** V2.8.14.49
- **TA Version** V2.8.13.36
- **Video Version** V2.8.12.1
- **Access Control** Applied License: Advanced  
Issued to: Peter  
Expiry date: None
- **Video** Issued to: Peter  
Expiry date: None
- **Visitor** Issued to: Peter  
Expiry date: None

© 2021 Suprema Inc. All rights reserved.

## Video Demo for Activating License for Biostar 2 Version 2.8.16 and Lower

[license.mp4](#)

From:

<http://kb.supremainc.com/knowledge/> -

Permanent link:

[http://kb.supremainc.com/knowledge/doku.php?id=en:how\\_to\\_activate\\_license&rev=1682404383](http://kb.supremainc.com/knowledge/doku.php?id=en:how_to_activate_license&rev=1682404383)

Last update: **2023/04/25 15:33**