2021/03/16 02:17 / How to delete a card

Table of Contents

How to delete a card	1
How to delete an EM, HID, and Mifare CSN card registered to the user	1


BioStar 1, Card

How to delete a card

BioStar supports four types of cards: EM, HID, Mifare CSN and Mifare Template cards. However, you can delete EM, HID and Mifare CSN cards only. It is impossible to delete a Mifare Template card since all the necessary information is not stored in the database, but in the card itself.

How to delete an EM, HID, and Mifare CSN card registered to the user


1. Go to the **User** page, choose a user from whom you want to delete a card in the **User** pane and click the **Card** tab.




2. Click Card Management, enter 0 in the Card ID field and click OK.

⁻ https://kb.supremainc.com/knowledge/

2021/03/16 02:17 2/2 How to delete a card



3. Click **Apply** to complete the card deletion process.



From:

https://kb.supremainc.com/knowledge/ -

Permanent link:

https://kb.supremainc.com/knowledge/doku.php?id=en:1xfaq_how_to_delete_a_card

Last update: 2015/10/13 11:01