

Table of Contents


How to delete users in device through BioStar 2	1
---	---

How to delete users in device through BioStar 2

From BioStar 2.7.1, you can delete user in device through server(BioStar 2).
FW should be compatible with BioStar 2.7.1.

- BioStation 2: 1.7.0 or later
- BioStation A2: 1.6.0 or later
- BioStation L2: 1.4.0 or later
- BioEntry W2: 1.3.0 or later
- FaceStation 2: 1.2.0 or later
- CoreStation: 1.2.0 or later
- BioEntry P2: 1.2.0 or later
- BioEntry R2: 1.2.0 or later
- BioLite N2: 1.1.0 or later
- XPass D2: 1.1.0 or later
- OM-120: 1.1.0 or later
- Secure I/O 2: 1.2.4 or later
- DM-20: 1.1.4 or later

In monitoring menu, you can see if the user enrolled from BioStar or device by log.



From:

<http://kb.supremainc.com/knowledge/> -

Permanent link:

http://kb.supremainc.com/knowledge/doku.php?id=en:how_to_delete_users_in_device_through_biostar_2&rev=1557728099

Last update: **2019/05/13 15:14**