

## Table of Contents

How to keep network settings during factory default .....	1
---	---

[System Configuration](#), [BioStar 2](#), [SIP](#), ["Videophone"](#)

# How to keep network settings during factory default

Before BioStar 2.6, some devices couldn't restore to default value without changing network setting. If you use Factory Default when you use static IP instead of DHCP, you need to reconfigure network. Every site does not always have a person who can manage the device. In this case, the installer has to visit the site directly.

To resolve this inconvenience, BioStar 2.6 provides an option 'Without network' for every device

The screenshot shows the BioStar 2 web interface for a device named 'BioStation 2 546832586 (192.168.14.228)'. The 'Information' section includes fields for Name, Device ID, Firmware Version, Kernel Version, and Time Zone. The 'Restore to default' section has two buttons: 'All' and 'Without Network', with the latter highlighted by a red box. The 'System' section shows the 'Display Date' as 2018/04/03 16:30:25. A sidebar on the left contains navigation links for DASH BOARD, USER, DEVICE, DOOR, ELEVATOR, ZONE, ACCESS CONTROL, and MONITORING.

From:  
<http://kb.supremainc.com/knowledge/> -

Permanent link:  
[http://kb.supremainc.com/knowledge/doku.php?id=en:how\\_to\\_keep\\_network\\_settings\\_during\\_factory\\_default&rev=1522829286](http://kb.supremainc.com/knowledge/doku.php?id=en:how_to_keep_network_settings_during_factory_default&rev=1522829286)

Last update: 2018/04/04 17:08