

## Table of Contents

How to keep network settings during factory default .....	1
---	---

System Configuration, BioStar 2, Network, "factory, default", restore to default, reset

# How to keep network settings during factory default

Before BioStar 2.6, some devices couldn't restore to default value without changing network setting. If you use Factory Default when you use static IP instead of DHCP, you need to reconfigure network. Every site does not always have a person who can manage the device. In this case, the installer has to visit the site directly.

To resolve this inconvenience, BioStar 2.6 provides an option 'Without network' for every device

The screenshot shows the BioStar 2 software interface. On the left is a vertical sidebar with icons for Dashboard, User, Device (highlighted in red), Door, Elevator, Zone, Access Control, and Monitoring. The main area shows a device configuration page for a BioStation 2 with IP 192.168.14.228. The 'Information' tab is selected. In the 'Restore to default' dropdown, the 'Without Network' option is highlighted with a red box. Other options in the dropdown include 'All' and 'Factory'. To the right of the dropdown, there are columns for Group, Device T, Product, Hardware, and Locked, each with a corresponding checkbox. Below the 'Information' tab, there is a 'System' section with a 'Display Date' field set to 2018/04/03 at 16:30:25, with a 'Get' button to its right.

From:

<http://kb.supremainc.com/knowledge/> -

Permanent link:

[http://kb.supremainc.com/knowledge/doku.php?id=en:how\\_to\\_keep\\_network\\_settings\\_during\\_factory\\_default&rev=1522829452](http://kb.supremainc.com/knowledge/doku.php?id=en:how_to_keep_network_settings_during_factory_default&rev=1522829452)

Last update: 2018/04/04 17:10