

<b>SDK API</b> .....	1
<b>initialize</b> .....	1
.....	1
<b>run</b> .....	1
.....	1
<b>getVersion</b> .....	2
.....	2
.....	2
<b>setCardType</b> .....	2
.....	2
.....	2
<b>connectFtpServer</b> .....	3
.....	3
.....	3
<b>disconnectFtpServer</b> .....	3
.....	3
<b>getFirmwareFileList</b> .....	3
.....	4
.....	4
<b>upgradeFirmware</b> .....	4
.....	4
.....	4

# SDK API

## initialize

SDK

```
void initialize(Context context, DeviceListener listener)
```

- context : android application context.
- listener : 가

DeviceListener

가 SDK가 가

## run

SDK

```
int run()
```

SUCCESS 가

SDK 가

# getVersion

SDK / Firmware 가 .

```
int getVersion(Version version)
```

- version : SDK / Firmware

Version

SUCCESS 가 .

# setCardType

RF .

```
int setCardType(int cardType)
```

- cardType : RF

1	HIGH_FREQUENCY
2	HIGH_FREQUENCY_ICLASS
3	LOW_FREQUENCY
4	LOW_FREQUENCY_PROX

SUCCESS 가 .

# connectFtpServer

FTP

```
int connectFtpServer(FirmwareOption option)
```

- option:

SUCCESS

가

API FTP

FTP

# disconnectFtpServer

FTP

```
int disconnectFtpServer()
```

SUCCESS

가

API FTP

FTP

# getFirmwareFileList

FTP

```
int getFirmwareFileList(ArrayList<String> fileList)
```

- fileList:

SUCCESS 가 .

API	FTP	FTP	.
-----	-----	-----	---

## upgradeFirmware

```
int upgradeFirmware(FirmwareOption option)
```

- option:

SUCCESS 가 .

API	FTP	FTP	.
-----	-----	-----	---

From:  
<http://kb.supremainc.com/svpsdk/> - **SVP Android SDK**

Permanent link:  
[http://kb.supremainc.com/svpsdk./doku.php?id=ko:sdk\\_api&rev=1543821685](http://kb.supremainc.com/svpsdk./doku.php?id=ko:sdk_api&rev=1543821685)

Last update: **2018/12/03 16:21**

