

**SDK API** ..... 1

***initialize*** ..... 1

        ..... 1

***run*** ..... 1

        ..... 1

***getVersion*** ..... 2

        ..... 2

        ..... 2

***setCardType*** ..... 2

        ..... 2

        ..... 2

***connectFtpServer*** ..... 3

        ..... 3

        ..... 3

***disconnectFtpServer*** ..... 3

        ..... 3

***getFirmwareFileList*** ..... 4

        ..... 4

        ..... 4

***upgradeFirmware*** ..... 4

        ..... 4

        ..... 4

# SDK API

## initialize

SDK

```
void initialize(Context context, DeviceListener listener)
```

- context : android application context.
- listener : 가

DeviceListener

가 SDK가 가

## run

SDK

```
int run()
```

SUCCESS 가

SDK 가

# getVersion

SDK / Firmware 가 .

```
int getVersion(Version version)
```

- version : SDK / Firmware

Version

SUCCESS 가 .

# setCardType

RF .

```
int setCardType(int cardType)
```

- cardType : RF

1	HIGH_FREQUENCY
2	HIGH_FREQUENCY_ICLASS
3	LOW_FREQUENCY
4	LOW_FREQUENCY_PROX

SUCCESS 가 .

# connectFtpServer

FTP

```
int connectFtpServer(FirmwareOption option)
```

- option:

FirmwareOption

SUCCESS 가

```

API FTP
FTP
\\
<uses-permission android:name="android.permission.INTERNET"/>
<uses-permission
android:name="android.permission.WRITE_EXTERNAL_STORAGE" />

```

# disconnectFtpServer

FTP

```
int disconnectFtpServer()
```

SUCCESS 가

API FTP FTP

## getFirmwareFileList

FTP

```
int getFirmwareFileList(ArrayList<String> fileList)
```

- fileList:

SUCCESS 가

API FTP

FTP

## upgradeFirmware

```
int upgradeFirmware(FirmwareOption option)
```

- option:

FirmwareOption

SUCCESS 가

API FTP

FTP

From:

<http://kb.supremainc.com/svpsdk/> - **SVP Android SDK**

Permanent link:

[http://kb.supremainc.com/svpsdk./doku.php?id=ko:sdk\\_api&rev=1543822755](http://kb.supremainc.com/svpsdk./doku.php?id=ko:sdk_api&rev=1543822755)

Last update: **2018/12/03 16:39**