

# Table of Contents

- BS2\_GetDeviceCapabilities*** ..... 1
- Declaration ..... 1
- Parameter ..... 1
- Return Value ..... 1

[Device API](#) > [BS2\\_GetDeviceCapabilities](#)

---

## BS2\_GetDeviceCapabilities

[+ V2.8] Get the device's capabilities such as card support or finger support.  
(SIO2 and DM-20 do not support this API.)

### Declaration

```
#include "BS_API.h"

int BS2_GetDeviceCapabilities(void* context, uint32_t deviceId,
BS2DeviceCapabilities* capabilities);
```

[See BS2DeviceCapabilities](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *capabilities* : Address which stores Device Capabilities

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.  
If there is an error, the corresponding error code will be returned.

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_getdevicecapabilities](https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getdevicecapabilities)

Last update: **2024/05/31 12:24**