

Table of Contents

BS2_GetLogBlobFromDirWithKey	1
Declaration	1
Parameters	1
Return value	1
See Also	1

[USB Exported Control API](#) > [BS2_GetLogBlobFromDirWithKey](#)

BS2_GetLogBlobFromDirWithKey

[+2.8.2] Import a certain amount of logs from the USB extracted data to match the Event Mask.

Declaration

```
#include "BS_API.h"

int BS2_GetLogBlobFromDirWithKey(void* context, const char* szDir, uint16_t
eventMask, BS2_EVENT_ID eventId, uint32_t amount, BS2EventBlob** logsObj,
uint32_t* numLog, const BS2EncryptKey* key);
```

[View the structure of the BS2EventBlob](#)

Parameters

- [In] *context* : Context
- [In] *szDir* : Data storage path
- [In] *eventMask* : event mask
- [In] *eventId* : Log record ID, if zero, imported from the beginning
- [In] *amount* : Maximum number of log records, if zero, gets all records since eventId.
- [Out] *logsObj* : Pointer to store the address of the log record
- [Out] *numLog* : Number of log records
- [In] *key* : Encryption key and the key value specified by [BS2_SetDataEncryptKey](#)

Note

The logsObj variable must be used and then returned to the system using the [BS2_ReleaseObject](#) function.

Return value

Returns BS_SDK_SUCCESS if performed successfully, or a corresponding error code if an error occurs.

See Also

[BS2_GetUserDatabaseInfoFromDirWithKey](#)

[BS2_GetUserListFromDirWithKey](#)

[BS2_GetUserInfosFromDirWithKey](#)

[BS2_GetUserDatasFromDirWithKey](#)

[BS2_GetUserInfosExFromDirWithKey](#)

[BS2_GetUserDatasExFromDirWithKey](#)

[BS2_GetLogFromDirWithKey](#)

[BS2_GetFilteredLogFromDirWithKey](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getlogblobfromdirwithkey

Last update: **2022/04/21 09:53**