

# Table of Contents

<b>BS2_GetRtspConfig</b> .....	1
함수 .....	1
파라미터 .....	1
반환값 .....	1

 **This page is not fully translated, yet. Please help completing the translation.**  
(remove this paragraph once the translation is finished)

[Configuration API](#) > [BS2\\_GetRtspConfig](#)

## BS2\_GetRtspConfig

[+ 2.8.3] BioStation 3 Gets the RTSP settings.

### 함수

```
#include "BS_API.h"

int BS2_GetRtspConfig(void* context, uint32_t deviceId, BS2RtspConfig* config);
```

[BS2RtspConfig 구조체 보기](#)

### 파라미터

- [In] *context* : Context
- [In] *deviceId* : 장치 식별자
- [Out] *config* : RTSP 설정 정보를 저장할 포인터

### 반환값

성공적으로 수행될 경우 `BS_SDK_SUCCESS`를 반환하고, 에러가 발생할 경우 상응하는 에러 코드를 반환합니다.

From:  
<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:  
[https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_getrtspconfig&rev=1662335809](https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getrtspconfig&rev=1662335809)

Last update: **2022/09/05 08:56**