

# Table of Contents

<b>BS2_GetRtspConfig</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1

[Configuration API](#) > [BS2\\_GetRtspConfig](#)

---

## BS2\_GetRtspConfig

[+ 2.8.3] BioStation 3 Gets the RTSP settings.

### Declaration

```
#include "BS_API.h"

int BS2_GetRtspConfig(void* context, uint32_t deviceId, BS2RtspConfig* config);
```

[see BS2RtspConfig Structure](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device Identifier
- [Out] *config* : Pointer to store RTSP settings information

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.  
If there is an error, the corresponding error code will be returned.

From:  
<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:  
[https://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2\\_getrtspconfig&rev=1662526185](https://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_getrtspconfig&rev=1662526185)

Last update: **2022/09/07 13:49**