

Table of Contents

BS2_SetRtspConfig	1
Declaration	1
Parameter	1
Return Value	1
Sample Code(C++)	1
샘플코드(C#)	2

[Configuration API](#) > [BS2_SetRtspConfig](#)

BS2_SetRtspConfig

[+ 2.8.3] Save the RTSP settings.

Declaration

```
#include "BS_API.h"

int BS2_SetRtspConfig(void* context, uint32_t deviceId, const BS2RtspConfig* config);
```

[See BS2RtspConfig Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : 장치 식별자
- [In] *config* : RTSP 설정 정보 포인터

Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

Sample Code(C++)

[sample_setrtspconfig.cpp](#)

```
BS2RtspConfig config = { , };

config.enabled = true;

string acc = "myAccount";
memset(config.id, 0x0, BS2_USER_ID_SIZE);
memcpy(config.id, acc.c_str(), acc.size());

string pw = "myPassword";
memset(config.password, 0x0, BS2_USER_ID_SIZE);
```

```
memcpy(config.password, pw.c_str(), pw.size());

string addr = "192.168.0.10"; // rtsp://192.168.0.10
memset(config.address, 0x0, BS2_URL_SIZE);
memcpy(config.address, addr.c_str(), addr.size());

config.port = 554;

int sdkResult = BS2_SetRtspConfig(context, deviceID, &config);
if (BS_SDK_SUCCESS != sdkResult)
    printf("BS2_SetRtspConfig call failed: %d", sdkResult);
```

샘플코드(C#)

sample_setrtspconfig.cs

```
BS2RtspConfig config = Util.AllocateStructure<BS2RtspConfig>();

config.enabled = Convert.ToByte(1);

string strRTSPID = "myAccount";
byte[] arrRTSPID = Encoding.UTF8.GetBytes(strRTSPID);
Array.Clear(config.id, , BS2Environment.BS2_USER_ID_SIZE);
Array.Copy(arrRTSPID, , config.id, , arrRTSPID.Length);

string strRTSPPW = "myPassword";
byte[] arrRTSPPW = Encoding.UTF8.GetBytes(strRTSPPW);
Array.Clear(config.password, , BS2Environment.BS2_USER_ID_SIZE);
Array.Copy(arrRTSPPW, , config.password, , arrRTSPPW.Length);

string strIpAddr = "192.168.0.10"; // rtsp://192.168.0.10
byte[] arrIpAddr = Encoding.UTF8.GetBytes(strIpAddr);
Array.Clear(config.address, , BS2Environment.BS2_URL_SIZE);
Array.Copy(arrIpAddr, , config.address, , arrIpAddr.Length);

config.port = (ushort)554;

BS2ErrorCode result = (BS2ErrorCode)API.BS2_SetRtspConfig(sdkContext,
deviceID, ref config);
if (result != BS2ErrorCode.BS_SDK_SUCCESS)
{
    Console.WriteLine("Got error({0}).", result);
}
```

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setrtsconfig

Last update: **2024/05/28 19:05**