

**BS2\_DeActivateFloor** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

# BS2\_DeActivateFloor

Floor가 , Floor가 .

```
#include "BS_API.h"

int BS2_DeActivateFloor(void* context, uint32_t deviceId, BS2_FLOOR_FLAG
flag, BS2_LIFT_ID liftID, uint16_t* floorIndexs, uint8_t floorIndexCount);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *flag* : 가 floor
- [In] *liftID* : lift ID
- [In] *floorIndexs* : floor Index
- [In] *floorIndexCount* : floor Index

BS\_SDK\_SUCCESS , 가

- [BS2\\_GetLift](#)
- [BS2\\_GetAllLift](#)
- [BS2\\_GetLiftStatus](#)
- [BS2\\_GetAllLiftStatus](#)
- [BS2\\_SetLift](#)
- [BS2\\_SetLiftAlarm](#)
- [BS2\\_RemoveLift](#)
- [BS2\\_RemoveAllLift](#)
- [BS2\\_ReleaseFloor](#)
- [BS2\\_ActivateFloor](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_deactivatefloor](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_deactivatefloor)

Last update: **2017/06/28 11:41**