

**BS2\_GetInputConfig** ..... 1  
..... 1  
..... 1  
..... 1

# BS2\_GetInputConfig

Supervised 가 . CS40, SIO2, DM20 .

```
#include "BS_API.h"

int BS2_GetInputConfig(void* context, uint32_t deviceId, BS2InputConfig* config);
```

BS2InputConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* :

BS\_SDK\_SUCCESS , 가

From:  
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:  
[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_getinputconfig](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getinputconfig)

Last update: **2020/09/29 10:57**