

**BS2\_GetThermalCameraConfig** ..... 1

..... 1

..... 1

..... 1

# BS2\_GetThermalCameraConfig

[+ 2.7.1] 가 .

```
#include "BS_API.h"

int BS2_GetThermalCameraConfig(void* context, uint32_t deviceId,
BS2ThermalCameraConfig* config);
```

BS2ThermalCameraConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* :

BS\_SDK\_SUCCESS , 가

From:  
<https://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:  
[https://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_getthermalcameraconfig](https://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getthermalcameraconfig)

Last update: **2024/05/28 19:01**