

BS2_GetUserDatasFaceExFromDirWithKey 1

..... 1

..... 1

..... 2

..... 2

BS2_GetUserDatasFaceExFromDirWithKey

[+2.8.2] USB Data 가 .
FaceStaion F2 export USB file .

```
#include "BS_API.h"

int BS2_GetUserDatasFaceExFromDirWithKey(void* context, const char* szDir,
char* uids, uint32_t uidCount, BS2UserFaceExBlob* userBlob, BS2_USER_MASK
userMask, const BS2EncryptKey* key);
```

[BS2UserFaceExBlob](#)

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :
- [In] *userMask* : Mask
- [In] *key* : [BS2_SetDataEncryptKey](#)

0x0000	
0x0001	data
0x0002	
0x0004	
0x0008	
0x0010	PIN
0x0020	
0x0040	
0x0080	
0x0100	
0x0200	
0x0400	
0x0800	(FaceStation F2)

0x1000	(FaceStation F2)
0xFFFF	

BS_SDK_SUCCESS , 가

BS2_GetUserInfosFaceExFromDirWithKey

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getuserdatasfaceexfromdirwithkey

Last update: **2022/04/12 15:38**