

USB Exported Control API 1

USB Exported Control API

Usb Exported

API

- [BS2_GetUserDatabaseInfoFromDir](#): Usb Data (, ,) 가 .
- [BS2_GetUserListFromDir](#): Usb Data ID 가 .
- [BS2_GetUserInfosFromDir](#): Usb Data ID 가 .
- [BS2_GetUserDatasFromDir](#): Usb Data UserMask ID 가 .
- [BS2_GetUserInfosExFromDir](#): Usb Data ID 가 . (Job, phrase v2.4)
- [BS2_GetUserDatasExFromDir](#): Usb Data UserMask ID 가 . (Job, phrase v2.4)
- [BS2_GetLogFromDir](#): Usb Data 가 .
- [BS2_GetLogBlobFromDir](#): Usb Data EventMask 가 .
- [BS2_GetFilteredLogFromDir](#): Usb Data 가 .

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:use_exported_control_api&rev=1540857729

Last update: **2018/10/30 09:02**