

USB Exported Control API 1

USB Exported Control API

USB Exported

API

- [BS2_GetUserDatabaseInfoFromDir](#): USB Data (, ,) 가
- [BS2_GetUserListFromDir](#): USB Data ID 가
- [BS2_GetUserInfosFromDir](#): USB Data ID 가
- [BS2_GetUserDatasFromDir](#): USB Data UserMask ID 가
- [BS2_GetUserInfosExFromDir](#): USB Data ID 가 . (Job, phrase v2.4)
- [BS2_GetUserDatasExFromDir](#): USB Data UserMask ID 가 . (Job, phrase v2.4)
- [BS2_GetLogFromDir](#): USB Data 가
- [BS2_GetLogBlobFromDir](#): USB Data EventMask 가
- [BS2_GetFilteredLogFromDir](#): USB Data 가

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=ko:use_exported_control_api&rev=1540857790

Last update: **2018/10/30 09:03**