

**USB Exported Control API** ..... 1

# USB Exported Control API

## USB Exported

## API

- [BS2\\_AllocateUsbContext](#):
- [BS2\\_ReleaseUsbContext](#):
- [BS2\\_GetUserDatabaseInfoFromDir](#): USB Data ( , ) 가
- [BS2\\_GetUserListFromDir](#): USB Data ID 가
- [BS2\\_GetUserInfosFromDir](#): USB Data ID 가
- [BS2\\_GetUserDatasFromDir](#): USB Data UserMask ID 가
- [BS2\\_GetUserInfosExFromDir](#): USB Data ID 가 . (Job, phrase v2.4 )
- [BS2\\_GetUserDatasExFromDir](#): USB Data UserMask ID 가 . (Job, phrase v2.4 )
- [BS2\\_GetLogFromDir](#): USB Data 가
- [BS2\\_GetLogBlobFromDir](#): USB Data EventMask 가
- [BS2\\_GetFilteredLogFromDir](#): USB Data 가

From: <https://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link: [https://kb.supremainc.com/bs2sdk/doku.php?id=ko:use\\_exported\\_control\\_api&rev=1540861940](https://kb.supremainc.com/bs2sdk/doku.php?id=ko:use_exported_control_api&rev=1540861940)

Last update: **2018/10/30 10:12**