

## Table of Contents

<b><i>BS2_GetAuthConfigExt</i></b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1

Configuration API > [BS2\\_GetAuthConfigExt](#)

## BS2\_GetAuthConfigExt

[+ 2.7.1] FaceStation F2 Only Retrieves authentication settings from the device.

### Tip

If **not FaceStation F2**, please use [BS2\\_GetAuthConfig](#).

## Declaration

```
#include "BS_API.h"

int BS2_GetAuthConfigExt(void* context, uint32_t deviceId, BS2AuthConfigExt*
config);
```

[See BS2AuthConfigExt Structure](#)

## Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : Authentication configurations pointer

## Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_getauthconfigext](http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getauthconfigext)

Last update: **2020/10/22 15:05**