

Table of Contents

<i>BS2_GetWiegandDeviceConfig</i>	1
Declaration	1
Parameter	1
Return Value	1

Configuration API > [BS2_GetWiegandDeviceConfig](#)

BS2_GetWiegandDeviceConfig

Retrieves Wiegand device settings from the device.

Declaration

```
#include "BS_API.h"

int BS2_GetWiegandDeviceConfig(void* context, uint32_t deviceId,
BS2WiegandDeviceConfig* config);
```

[See BS2WiegandDeviceConfig Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : Wiegand signal configurations pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getwieganddeviceconfig

Last update: **2016/07/12 09:19**