

<b>BS2_GetConfig</b>	.....	1
.....	.....	1
.....	.....	1
.....	.....	1

Configuration API > BS2\_GetConfig

## BS2\_GetConfig

Configuration blob 가

```
#include "BS_API.h"

int BS2_GetConfig(void* context, uint32_t deviceId, BS2Configs* configs);
```

BS2Configs

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *configs* : configuration blob.

configs configMask 가

BS\_SDK\_SUCCESS , 가

From:

<http://kb.supremainc.com/bs2sdk/> - BioStar 2 Device SDK

Permanent link:

[http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_getconfig](http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_getconfig)

Last update: 2016/07/12 09:16