

<b>BS2_GetIPv6ConfigViaUDPEx</b>	.....	1
.....	.....	1
.....	.....	1
.....	.....	1
.....	.....	1

Configuration API > [BS2\\_GetIPV6ConfigViaUDPEx](#)

## BS2\_GetIPV6ConfigViaUDPEx

[+ 2.6.3] Host ip , IP V6 udp broadcasting 가 .  
Ethernet card가 .

```
#include "BS_API.h"

int BS2_GetIPV6ConfigViaUDPEx(void* context, uint32_t deviceId,
BS2IPV6Config* config, const char* hostipAddr);
```

BS2IPV6Config

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : IP V6
- [In] *hostipAddr* : IP

BS\_SDK\_SUCCESS , 가

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2\\_getipv6configviaudpex](http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getipv6configviaudpex)

Last update: **2019/05/13 11:38**