

BS2_SetStatusConfig	1
	1
	1
	1

Configuration API > BS2_SetStatusConfig

BS2_SetStatusConfig

led, buzzer

```
#include "BS_API.h"

int BS2_SetStatusConfig(void* context, uint32_t deviceId, BS2StatusConfig*
config);
```

BS2StatusConfig

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : led, buzzer

BS_SDK_SUCCESS , 가

From:

<http://kb.supremainc.com/bs2sdk/> - BioStar 2 Device SDK

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setstatusconfig

Last update: 2016/07/12 09:31