

Table of Contents

BS2_GetAuthConfig	1
Declaration	1
Parameter	1
Return Value	1

[Configuration API](#) > [BS2_GetAuthConfig](#)

BS2_GetAuthConfig

Retrieves authentication settings on the device

Declaration

```
#include "BS_API.h"

int BS2_GetAuthConfig(void* context, uint32_t deviceId, BS2AuthConfig* config);
```

[See BS2AuthConfig Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : Authentication configurations pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_getauthconfig

Last update: **2016/07/12 09:10**