

Table of Contents

BS2_GetEnableIPV4	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Communication API](#) > [BS2_GetEnableIPV4](#)

BS2_GetEnableIPV4

[+ 2.6.3] Gets IPv4 connection mode.

Declaration

```
#include "BS_API.h"

int BS2_GetEnableIPV4(void* context, int* enable);
```

Parameter

- [In] *context* : Context
- [Out] *enable* : Weather IPv4 connection is enabled

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

See Also

[BS2_SetEnableIPV4](#)

From:
<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getenableipv4

Last update: **2019/05/28 11:45**