


Table of Contents

| | |
|---------------------------------------|---|
| BS2_GetRelayActionConfig | 1 |
| 함수 | 1 |
| Parameters | 1 |
| Return Values | 1 |

 **This page is not fully translated, yet. Please help completing the translation.**
(remove this paragraph once the translation is finished)

[Configuration API](#) > [BS2_GetRelayActionConfig](#)

BS2_GetRelayActionConfig

[+ 2.8.1] IM- 120 Retrieves RelayAction Settings.

함수

```
#include "BS_API.h"

int BS2_GetRelayActionConfig(void* context, uint32_t deviceId,
BS2RelayActionConfig* config);
```

[BS2RelayActionConfig Structure](#)

Parameters

- [In] *context* : Context
- [In] *deviceId* : Device Identifier
- [Out] *config* : Pointer where Input Expandable Setting Information will be saved

Return Values

Return BS_SDK_SUCCESS when successful, and return an appropriate error code when an error occurs.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getrelayactionconfig&rev=1628205320

Last update: **2021/08/06 08:15**