

Table of Contents

BS2_GetRS485Config

Declaration

Parameter

Return Value

..... 1

..... 1

..... 1

..... 1

[Configuration API](#) > [BS2_GetRS485Config](#)

BS2_GetRS485Config

Retrieves RS-485 network settings from the device.

Declaration

```
#include "BS_API.h"

int BS2_GetRS485Config(void* context, uint32_t deviceId, BS2Rs485Config* config);
```

[See BS2Rs485Config Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : RS-485 network configurations pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getrs485config

Last update: **2016/07/12 09:22**