

Table of Contents

BS2_GetUserInfosEx	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[User Management API](#) > [BS2_GetUserInfosEx](#)

BS2_GetUserInfosEx

Gets the user information of the given user ID. This API is only for devices that has been upgraded to the v2.4 FW group. You can check the FW list from the v2.4 release notes.

Declaration

```
#include "BS_API.h"

int BS2_GetUserInfosEx(void* context, uint32_t deviceId, char* uids,
uint32_t uidCount, BS2UserBlobEx* userBlob);
```

[See BS2UserBlobEx Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *uids* : User ID list trying to get
- [In] *uidCount* : Number of user ID
- [Out] *userBlob* : Pointer to store the user information

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetUserList](#)
[BS2_EnrolUserEx](#)
[BS2_RemoveUser](#)
[BS2_RemoveAllUser](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getuserinfosex

Last update: **2017/03/21 11:40**