

# Table of Contents

<b>BS2_GetUserInfosFaceExFromDir</b> .....	1
Declaration .....	1
Parameters .....	1
Return value .....	1
See Also .....	1

[USB Exported Control API](#) > [BS2\\_GetUserInfosFaceExFromDir](#)

---

## BS2\_GetUserInfosFaceExFromDir

[+2.7.1] Gets the user information corresponding to the user identifier from the data extracted by USB. Supports USB files exported from FaceStation F2 devices.

### Declaration

```
#include "BS_API.h"

int BS2_GetUserInfosFaceExFromDir(void* context, const char* szDir, char*
uids, uint32_t uidCount, BS2UserFaceExBlob* userBlob);
```

[View the structure of the BS2UserFaceExBlob](#)

### Parameters

- [In] *context* : Context
- [In] *szDir* : Data storage path
- [In] *uids* : List of user identifiers to be imported
- [In] *uidCount* : Number of user identifiers
- [Out] *userBlob* : Pointer to store user information

### Return value

Returns BS\_SDK\_SUCCESS if performed successfully, or a corresponding error code if an error occurs.

### See Also

[BS2\\_GetUserDatasFaceExFromDir](#)

From:  
<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:  
[https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_getuserinfosfaceexfromdir](https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getuserinfosfaceexfromdir)

Last update: **2022/04/21 10:36**

