Table of Contents

Face API > BS2_RemoveAuthGroup

BS2_RemoveAuthGroup

Removes selected authentication groups.

Declaration

```
#include "BS_API.h"

int BS2_RemoveAuthGroup(void* context, uint32_t deviceId, uint32_t*
authGroupIds, uint32_t authGroupIdCount);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *authGroupIds* : List of authentication groups to remove
- [In] *authGroupIdCount* : Number of authentication groups to remove

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

BS2_GetAuthGroup
BS2_GetAllAuthGroup
BS2_SetAuthGroup
BS2_RemoveAllAuthGroup

From:
https://kb.supremainc.com/bs2sdk/ - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_removeauthgroup

Last update: **2017/06/28 10:58**