

Table of Contents

BS2_RunAction	1
API	1
Parameters	1
Return Values	1

 **This page is not fully translated, yet. Please help completing the translation.**
(remove this paragraph once the translation is finished)

[Device API](#) > [BS2_RunAction](#)

BS2_RunAction

[+ 2.8.1] Commands the device to take certain actions.
Using this API, you can control LED, buzzer, sound, relay and more.

API

```
#include "BS_API.h"

int BS2_RunAction(void* context, uint32_t deviceId, const BS2Action*
action);
```

[BS2Action Structure](#)

Parameters

- [In] *context* : Context
- [In] *deviceId* : Device Identifier
- [In] *action* : Address where certain actions are defined

Return Values

Return BS_SDK_SUCCESS when successful, and return an appropriate error code when an error occurs.

From:
<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_runaction&rev=1628145741

Last update: **2021/08/05 15:42**