

Table of Contents

BS2_SetAutoConnection	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Communication API](#) > [BS2_SetAutoConnection](#)

BS2_SetAutoConnection

Set auto connection.

If it is set, it automatically calls the connected callback function specified in [BS2_SetDeviceEventListener](#) after the socket connection from the device is accepted.

Declaration

```
#include "BS_API.h"

int BS2_SetAutoConnection(void* context, int enable);
```

Parameter

- [In] *context* : Context
- [In] *enable* : Weather auto connection is enabled

Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

See Also

[BS2_IsAutoConnection](#)

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setautoconnection

Last update: **2018/11/02 12:17**