

Table of Contents

BS2_SetBarcodeScanListener	1
Declaration	1
Parameters	1
Return value	1

[Server API](#) > [BS2_SetBarcodeScanListener](#)

BS2_SetBarcodeScanListener

[+2.8.2] Register the listener function that detects barcode input.

Declaration

```
#include "BS_API.h"

int BS2_SetBarcodeScanListener(void* context, OnBarcodeScanned
ptrBarcodeScanned);
```

Parameters

- [In] *context* : Context
- [In] *ptrBarcodeScanned* : Callback function to receive barcode when the device is scanned

Return value

Returns BS_SDK_SUCCESS if performed successfully, or a corresponding error code if an error occurs.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setbarcodescanlistener

Last update: **2022/04/19 14:16**