Table of Contents

Configuration API > BS2_SetDstConfig

BS2_SetDstConfig

[+ V2.6.0] Sets the device DST information.

Declaration

```
#include "BS_API.h"

int BS2_SetDstConfig(void* context, uint32_t deviceId, BS2DstConfig*
config);
```

> BS2DstConfig Structure

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *config* : DST settings pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

From:
http://kb.supremainc.com/bs2sdk/ - **BioStar 2 Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setdstconfig&rev=1522285012

Last update: **2018/03/29 09:56**