

# Table of Contents

<b>BS2_SetKeepAliveTimeout</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1

[Device API](#) > [BS2\\_SetKeepAliveTimeout](#)

---

## BS2\_SetKeepAliveTimeout

Sets the keep-alive timeout.

### Declaration

```
#include "BS_API.h"

int BS2_SetKeepAliveTimeout(void* context, long ms);
```

### Parameter

- [In] *context* : Context
- [In] *ms* : Keep-alive timeout (microsecond) Default value is 30,000,000.

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

From:

<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

[https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_setkeepalivetimeout&rev=1531790604](https://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setkeepalivetimeout&rev=1531790604)

Last update: **2018/07/17 10:23**