

# Table of Contents

<b>BS2_SetMaxThreadCount</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1

[SDK API](#) > [BS2\\_SetMaxThreadCount](#)

---

## BS2\_SetMaxThreadCount

Specifies the maximum thread count.

### Declaration

```
#include "BS_API.h"

int BS2_SetMaxThreadCount(void* context, uint32_t maxThreadCount);
```

### Parameter

- [In] *context* : Context
- [Out] *maxThreadCount* : Maximum thread count

#### NOTE

The default thread count is 4\*cpu core. You can't set this lower than 8.

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_setmaxthreadcount](http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setmaxthreadcount)

Last update: **2019/02/21 17:40**