

BS2_GetDstConfig	1
	1
	1
	1

Configuration API > BS2_GetDstConfig

BS2_GetDstConfig

[+ V2.6.0] DST 가 .

```
#include "BS_API.h"

int BS2_GetDstConfig(void* context, uint32_t deviceId, BS2DstConfig*
config);
```

BS2DstConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : DST

BS_SDK_SUCCESS , 가

From:

<http://kb.supremainc.com/bs2sdk/> - BioStar 2 Device SDK

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getdstconfig

Last update: 2018/03/11 20:40